



duet

Water Revitalizer User's Manual

Model No. DU-420

Your Duet Water Revitalizer

The spiral movement combined with other natural forces causes the molecules in water to become highly organized. They form a liquid crystal. Many scientists believe that maintaining the liquid crystalline properties of water within our bodies supports vibrant life and longevity.

The Duet allows you to compose your own water symphony using the same natural forces used by Mother Nature: Vortex Energy, Magnetic Fields, Far-Infrared wavelengths, and the Alkalinity-Enhancing Mineral Basket. The Duet returns water to its living, liquid crystalline state with high levels of oxygen and vital energy. Drinking water made in the Duet Water Revitalizer enhances your body's ability to maintain balance. It augments any nutritional program and any form of health maintenance.

Put the “life” back in your water and the zest back in your life with this elegant, simple-to-use water system.

Limited Warranty Statement


Duet Water Revitalizer warrants to the original purchaser only, that each Duet unit shall be free from defects in materials and workmanship for five years from the purchase date. Should any such defects arise; the product will be replaced or repaired without charge by Tribest promptly upon the return of the defective product and a copy of proof of purchase to Tribest. All shipping costs are the responsibility of the user.

The warranty obligations of Tribest and the original purchaser's sole remedy shall be limited to repair or replacement of the product only. Tribest shall not be liable or responsible under any circumstances or in any amount for consequential or incidental damage of for injury or damages to persons or property using or used with or in connection with the product, or loss of profits or other costs or expenses of any kind or character.


There are no warranties or representations by Tribest other than as set forth above, either expressed or implied and no person, firm, or corporation is authorized to make any representation or incur any obligation in the name of or on behalf of Tribest except as stated above.

Getting Started

Follow these easy steps to assemble your Duet Water Revitalizer:



1. Hand wash the following using a sponge with mild detergent: pitcher, lid, spinner, and silicone ring. Rinse well.



2. Rinse the mineral basket under cold running tap water for a few seconds. Wipe it with a soft sponge or washcloth without detergent. Rinse well. **DO NOT USE DETERGENT OR SOAP TO WASH THE MINERAL BASKET.**

3. Place the spinner in the middle of the mineral basket.



4. Position the mineral basket inside the pitcher. Push it down at the bottom, and secure the basket by rotating it clockwise (to the right) with a little pressure.

Initial Cleaning:




1. Fill the pitcher with filtered water.
2. Place the pitcher on top of the base then press the power button.
3. Press the minute button, choose 9 minutes, then press the start button.
4. During the first cycle, it is normal that small particles could come out from the mineral basket.
5. Wait until the Duet has completed its cycle.
6. Empty the pitcher

If the Duet had not been used for an extended period of time, we recommend performing cleaning steps.

Operation

1. Pour filtered water into the pitcher.
2. Place the pitcher on top of the base.
3. Turn power on.
4. Press the minute button to select cycle time (9, 18, 27 minutes).
5. Press the start/ stop button to operate. The LED display will show the remaining minutes during the operation. When it is finished, zero "0" will appear on the LED display and the system will automatically stop.

Do not remove the pitcher from the base while the unit is in operation. If you wish to stop the unit at anytime press the start/ stop button to cancel the operation.



Tips for use:

- Always ensure that the middle portion of the base is dry. Wipe out with soft dry cloth any spilled water.
- Remove the mineral basket from the pitcher when cleaning the pitcher, lid, and spinner. To remove the mineral basket from the pitcher, turn the basket counter clockwise (to the left). Regularly wash the pitcher, lid, and spinner using a soft sponge with mild detergent. Rinse well.
- Clean your mineral basket with water and wipe with a wet, soft sponge or washcloth, without soap or detergent. Do not use detergent or soap.

Storing Revitalized Water:

For cool, great tasting, and refreshing water, we recommend storing your Revitalized Water in the refrigerator. If you prefer to keep your water outside the refrigerator, make sure to keep it in a cool place indirect to sunlight.


Precaution:

- To prevent possible electric shock, DO NOT immerse the Duet base in water.
- DO NOT use detergent or soap to wash the mineral basket.
- DO NOT attempt to disassemble the unit.
- DO NOT add hot water.

Capacity

2.2 liters/ 0.6 gallons.

Reminder



Warning

- If you have health problems or currently using electronic medical/ health device inside your body, consult a physician before using the Duet Water Revitalizer.
- Pregnant women are advised to consult a physician before using the Duet Water Revitalizer.

Trouble-Shooting

“When the power button is not working.”

- Check the power outlet if the machine is properly plugged in.

“Water in the pitcher is not rotating.”

- Check and make sure that the power is on, press minute button and then press start/ stop button.
- Make certain that the spinner with the silicone ring is place at the center of the mineral basket.
- Check if the mineral basket is securely placed at the bottom center inside the pitcher.
- Check if the pitcher is properly placed on the base of the Duet.


“Strange noise coming from the pitcher.”

- Check if the silicone ring is broken.
- Check if the silicone ring is flatly warped around the spinner.
- Make certain that there is nothing inside the pitcher except water, spinner with silicone ring, and the mineral basket.

Added Feature


The Duet Water Revitalizer has a timer that inform users to discard/ replace used mineral basket:

When you have used your mineral basket for a total of 3,000 minutes “CC” message (change cube) lights on the display. It is very important to replace the mineral basket when “CC” starts flashing on the display.



Instructions for mineral basket replacement:

1. Unlock the used/ old basket from the pitcher by turning it counter clockwise (to the left). Remove old basket.
2. Position the new basket (with spinner and silicone ring) at the bottom center of the pitcher then rotate it clockwise (to the right) to secure the new basket inside the pitcher.
3. Run the machine for 9 minutes to clean the basket.
Do not drink this water.
4. To clear previous minutes used, press the minute and start/stop button simultaneously for 2 to 3 seconds until CL (Clear) appears on the display.
5. You're ready to use your Duet Water Revitalizer with a new mineral basket.



Follow these procedures to determine the total time you have used the mineral basket:


- Press the minute button for 2 to 3 seconds F1 appears on the LED display, this represents the total hours used.
- Press again the minute button for few seconds, F2 shows, which means total minutes used.
- Continue to press the minute button for another 2 to 3 seconds; F3 flashes, this is for total seconds used.
- Finally, when F4 appears, its for manufacturer's use only for additional system function.



Check the following parts before use:

- Lid
- Pitcher
- Spinner and Silicone Ring
- Mineral Basket
- Vitalizer Base

Parts





Tribest Corporation, Anaheim, CA 92801
Toll free: 888.254.7336 | Tel: 714.879.7150
service@tribest.com | www.tribest.com